


INSTALLATION INSTRUCTIONS



PREPARE FOR ASSEMBLY




INSTALLATION INSTRUCTIONS



PREPARE FOR ASSEMBLY

INSTALLATION INSTRUCTIONS



PREPARE FOR ASSEMBLY

INSTALLATION INSTRUCTIONS



PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS

4

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS



5

PREPARE FOR ASSEMBLY




INSTALLATION INSTRUCTIONS

6

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS



PREPARE FOR ASSEMBLY


INSTALLATION INSTRUCTIONS

8

PREPARE FOR ASSEMBLY




INSTALLATION INSTRUCTIONS



PREPARE FOR ASSEMBLY

INSTALLATION INSTRUCTIONS



10

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS

11

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS




12

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS



13

PREPARE FOR ASSEMBLY




INSTALLATION INSTRUCTIONS



14

PREPARE FOR ASSEMBLY

INSTALLATION INSTRUCTIONS




15



PREPARE FOR ASSEMBLY

INSTALLATION INSTRUCTIONS



16

PREPARE FOR ASSEMBLY

INSTALLATION INSTRUCTIONS



PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS



18

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS

19

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS



20

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS


21

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS

22



PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS

23

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS

24

PREPARE FOR ASSEMBLY




INSTALLATION INSTRUCTIONS

25

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS




26

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS


27



PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS



28



PREPARE FOR ASSEMBLY

INSTALLATION INSTRUCTIONS

29

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS

30

PREPARE FOR ASSEMBLY




INSTALLATION INSTRUCTIONS

31

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS



32

PREPARE FOR ASSEMBLY




INSTALLATION INSTRUCTIONS

32

PREPARE FOR ASSEMBLY





INSTALLATION INSTRUCTIONS

33

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS

34

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS

35

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS

35

PREPARE FOR ASSEMBLY




INSTALLATION INSTRUCTIONS

35

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS



36



PREPARE FOR ASSEMBLY


INSTALLATION INSTRUCTIONS

36

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS




37

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS




38

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS



39

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS


40

PREPARE FOR ASSEMBLY



ELEC
TRD


INSTALLATION INSTRUCTIONS



PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS



42

PREPARE FOR ASSEMBLY




INSTALLATION INSTRUCTIONS

43




PREPARE FOR ASSEMBLY

INSTALLATION INSTRUCTIONS




PREPARE FOR ASSEMBLY

INSTALLATION INSTRUCTIONS



PREPARE FOR ASSEMBLY

INSTALLATION INSTRUCTIONS



45

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS

46

PREPARE FOR ASSEMBLY



INSTALLATION INSTRUCTIONS


46



PREPARE FOR ASSEMBLY




INSTALLATION INSTRUCTIONS



WIRE HARNESS


INSTALLATION INSTRUCTIONS



WIRE HARNESS



INSTALLATION INSTRUCTIONS



WIRE HARNESS




INSTALLATION INSTRUCTIONS



WIRE HARNESS




INSTALLATION INSTRUCTIONS



WIRE HARNESS




INSTALLATION INSTRUCTIONS




WIRE HARNESS

INSTALLATION INSTRUCTIONS



WIRE HARNESS

INSTALLATION INSTRUCTIONS




B

2

WIRE HARNESS




INSTALLATION INSTRUCTIONS



WIRE HARNESS




INSTALLATION INSTRUCTIONS



WIRE HARNESS




INSTALLATION INSTRUCTIONS



WIRE HARNESS




INSTALLATION INSTRUCTIONS



WIRE HARNESS

INSTALLATION INSTRUCTIONS



4


E

F

WIRE HARNESS



INSTALLATION INSTRUCTIONS




connect cable

connect cable

WIRE HARNESS




INSTALLATION INSTRUCTIONS



WIRE HARNESS



INSTALLATION INSTRUCTIONS



WIRE HARNESS



INSTALLATION INSTRUCTIONS

5

38

0

WIRE HARNESS



INSTALLATION INSTRUCTIONS


5

38

38


38

WIRE HARNESS



INSTALLATION INSTRUCTIONS

6




WIRE HARNESS



INSTALLATION INSTRUCTIONS

7




39



WIRE HARNESS

INSTALLATION INSTRUCTIONS

8



39



WIRE HARNESS

INSTALLATION INSTRUCTIONS

9



43


WIRE HARNESS



INSTALLATION INSTRUCTIONS

9

43



WIRE HARNESS



INSTALLATION INSTRUCTIONS

10

42

WIRE HARNESS



INSTALLATION INSTRUCTIONS

10

43

42

WIRE HARNESS



ELECTRO
TWO

INSTALLATION INSTRUCTIONS

11

WIRE HARNESS



INSTALLATION INSTRUCTIONS

12

32

30

WIRE HARNESS



INSTALLATION INSTRUCTIONS

13

32

WIRE HARNESS



INSTALLATION INSTRUCTIONS

14

35

WIRE HARNESS



INSTALLATION INSTRUCTIONS

15

31

WIRE HARNESS



INSTALLATION INSTRUCTIONS

16


30

WIRE HARNESS



INSTALLATION INSTRUCTIONS

17



35

WIRE HARNESS



INSTALLATION INSTRUCTIONS

18


44

WIRE HARNESS



INSTALLATION INSTRUCTIONS

19



WIRE HARNESS



INSTALLATION INSTRUCTIONS

20



WIRE HARNESS



INSTALLATION INSTRUCTIONS


20



WIRE HARNESS



INSTALLATION INSTRUCTIONS



21

46

WIRE HARNESS



INSTALLATION INSTRUCTIONS

22

45

WIRE HARNESS



INSTALLATION INSTRUCTIONS

23

45

WIRE HARNESS



INSTALLATION INSTRUCTIONS


23

45

46

WIRE HARNESS





41

WIRE HARNESS



INSTALLATION INSTRUCTIONS

24



WIRE HARNESS



INSTALLATION INSTRUCTIONS

25

BR

WIRE HARNESS



INSTALLATION INSTRUCTIONS

25

BR

41


WIRE HARNESS



ELECTRO

INSTALLATION INSTRUCTIONS

26



BR

WIRE HARNESS




BR



WIRE HARNESS



INSTALLATION INSTRUCTIONS



27

E

F

WIRE HARNESS



INSTALLATION INSTRUCTIONS

27

E

F




WIRE HARNESS



Magic Start Choke

INSTALLATION INSTRUCTIONS

29



Magic Start Choke



INSTALLATION INSTRUCTIONS

30



Magic Start Choke



INSTALLATION INSTRUCTIONS

31

TURN FOR MORE RPM

TURN FOR LESS RPM

Pull to activate choke

Magic Start Choke



INSTALLATION INSTRUCTIONS

32

26



ASSEMBLY

INSTALLATION INSTRUCTIONS


33

25



ASSEMBLY





29




ASSEMBLY

INSTALLATION INSTRUCTIONS

35

28



ASSEMBLY



INSTALLATION INSTRUCTIONS

36

24

ASSEMBLY



INSTALLATION INSTRUCTIONS

37

22




ASSEMBLY

INSTALLATION INSTRUCTIONS

37

22

ASSEMBLY



INSTALLATION INSTRUCTIONS

38

20

ASSEMBLY



INSTALLATION INSTRUCTIONS

39

19



ASSEMBLY



INSTALLATION INSTRUCTIONS

40

17



ASSEMBLY

INSTALLATION INSTRUCTIONS

41

18

ASSEMBLY



INSTALLATION INSTRUCTIONS

42

21



ASSEMBLY



INSTALLATION INSTRUCTIONS

43

14

ASSEMBLY



INSTALLATION INSTRUCTIONS

44


13

ASSEMBLY



INSTALLATION INSTRUCTIONS

45




36



ASSEMBLY

INSTALLATION INSTRUCTIONS

46



ASSEMBLY

INSTALLATION INSTRUCTIONS

47

16

ASSEMBLY



INSTALLATION INSTRUCTIONS

48


15



ASSEMBLY

INSTALLATION INSTRUCTIONS

49



WIRE HARNESS

INSTALLATION INSTRUCTIONS

50



WIRE HARNESS

INSTALLATION INSTRUCTIONS

51



Z



WIRE HARNESS

INSTALLATION INSTRUCTIONS

52



WIRE HARNESS




INSTALLATION INSTRUCTIONS

53

Z




WIRE HARNESS



INSTALLATION INSTRUCTIONS

54



WIRE HARNESS



INSTALLATION INSTRUCTIONS

55



WIRE HARNESS

INSTALLATION INSTRUCTIONS

D

M

WIRE HARNESS






WIRE HARNESS



INSTALLATION INSTRUCTIONS

57



D

WIRE HARNESS





WIRE HARNESS




INSTALLATION INSTRUCTIONS

59

D


C

WIRE HARNESS



INSTALLATION INSTRUCTIONS

60



WIRE HARNESS

INSTALLATION INSTRUCTIONS

61

M

WIRE HARNESS



INSTALLATION INSTRUCTIONS

62

M



WIRE HARNESS



INSTALLATION INSTRUCTIONS

63

WIRE HARNESS



INSTALLATION INSTRUCTIONS

64

11



ASSEMBLY

INSTALLATION INSTRUCTIONS

65

10

ASSEMBLY



INSTALLATION INSTRUCTIONS

66

8

9


ASSEMBLY



INSTALLATION INSTRUCTIONS

67

7



ASSEMBLY



INSTALLATION INSTRUCTIONS

68

6



INSTALLATION INSTRUCTIONS

69

5



ASSEMBLY




INSTALLATION INSTRUCTIONS

70

4

ASSEMBLY



INSTALLATION INSTRUCTIONS

1

HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

2



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS

3




HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS


4



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS

5




HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

6



HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS


7

HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

8




HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS


9



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS

10




HARDWARE ASSEMBLY



ELECTRO

INSTALLATION INSTRUCTIONS

11




HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

12




HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

13



HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

14



HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS




P



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS

15

P

HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS


16

HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

17




HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

17




HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

18



HARDWARE ASSEMBLY





HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS


19



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS


20



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS


21



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS

22



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS

23




HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS


24



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS

25



HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

26




HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

27



HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

28



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS



HARDWARE ASSEMBLY





HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

30



HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

31



HARDWARE ASSEMBLY




INSTALLATION INSTRUCTIONS

32



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS




HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS

33

R

HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS


34

P

R




HARDWARE ASSEMBLY




INSTALLATION INSTRUCTIONS

35



HARDWARE ASSEMBLY

INSTALLATION INSTRUCTIONS




HARDWARE ASSEMBLY




INSTALLATION INSTRUCTIONS

36




HARDWARE ASSEMBLY



HARDWARE ASSEMBLY





HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

39

N

K



HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

40

HARDWARE ASSEMBLY



INSTALLATION INSTRUCTIONS

41


K

E

F



WIRE HARNESS



INSTALLATION INSTRUCTIONS

42

L

+

-

WIRE HARNESS



INSTALLATION INSTRUCTIONS

43

G

SE3
XTREM
battery

WIRE HARNESS



INSTALLATION INSTRUCTIONS

44

G

WIRE HARNESS



INSTALLATION INSTRUCTIONS

45


J

WIRE HARNESS



INSTALLATION INSTRUCTIONS

46




WIRE HARNESS



INSTALLATION INSTRUCTIONS

47




WIRE HARNESS



INSTALLATION INSTRUCTIONS

48

J




WIRE HARNESS



INSTALLATION INSTRUCTIONS

49



WIRE HARNESS

INSTALLATION INSTRUCTIONS

50

H

WIRE HARNESS



INSTALLATION INSTRUCTIONS

TO STARTER +

FROM BATTERY

51

K

J


H

WIRE HARNESS



INSTALLATION INSTRUCTIONS

51



WIRE HARNESS



Grease

S

WIRE HARNESS



INSTALLATION INSTRUCTIONS

53



WIRE HARNESS





WIRE HARNESS



INSTALLATION INSTRUCTIONS

55


S

R

WIRE HARNESS



INSTALLATION INSTRUCTIONS



56

F

T

U

V

G

T



INSTALLATION INSTRUCTIONS


57



WIRE HARNESS

INSTALLATION INSTRUCTIONS

58




WIRE HARNESS



INSTALLATION INSTRUCTIONS

59

H



WIRE HARNESS



INSTALLATION INSTRUCTIONS

60

H

WIRE HARNESS



INSTALLATION INSTRUCTIONS

61



WIRE HARNESS



INSTALLATION INSTRUCTIONS

62



Tighten all screws again

WIRE HARNESS



INSTALLATION INSTRUCTIONS

62




WIRE HARNESS



INSTALLATION INSTRUCTIONS


63



ASSEMBLY

INSTALLATION INSTRUCTIONS

64



ASSEMBLY

